

Sunpro Brand by Arizona RV Parts, Inc

Fastener Installation Instructions

Twist Lock Installation Instructions For Sun Shade Material

1. Push eyelet (grommet with spikes) through the front side of the material in desired area.
2. On the backside put the flat washer in the middle of the eyelet.
3. With pliers bend the eyelet spikes over towards the center of the eyelet.
4. Cut out the material in the center of the eyelet with a utility or Exacto™ knife.
5. Drill hole with provided drill bit and screw twist lock into hole and tighten till snug. It is recommended that you sue silicone on the tip of the screw before installing the twist lock. Use the same method of drilling snaps as well.

Dual Lock Installation Instructions

1. Clean area with denatured alcohol.
2. Attach the Dual Lock to the Dual Lock on the fabric; line up the fabric on you RV and mark Dual Lock location with a small pencil mark such as, a dot.
3. Peel the paper off of the Dual Lock and push it firmly into place. If you make a mistake you can peel up the dual lock and reapply it. Always be careful not to damage paint.
4. The adhesive reaches optimum adhesion after 24 hours.

Please Note: Arizona RV Parts, Inc. & Sunpro Mfg. assumes no responsibility for damage to your RV from an incorrect installation. If you are unsure of what to do please call us or have a qualified RV Service Center do the installation for you at your expense.

If you have questions call 800-789-5588

www.arizonarvparts.com
www.sunpromfg.com

www.sunpromfg.com

For a complete line of sun protection products or anything you might need for your RV visit our website or call us toll free @ **800-789-5588**.